



Open the Database Editor

Start SpaceCAD, open the Tools menu and select "Database Editor"



Check the DB location



Select and copy/paste the database's location,

open a Windows explorer window,

edit the **material.csv** file with a text editor (not Excel!).

Add a new line according to the first line:

```
Material Name,Units,Density,Low,High,Class,Rocketry Use,Body Tubes,Fin Sets,Launch  
Lugs,Cords,Nose,Chute,Stream,Trans, Ring,Bulkhead,Engine Block,Sleeve,Tube  
Coupler,spare,spare,spare,spare,spare,spare,spare,spare,spare,spare
```



For example:

```
Balsa,g/mm3,0.00012815,-1,-1,unknown,y,y,n,y,y,y,y,y,y,y,y,y,y,y,y,y,y,y,y
```

Restart SpaceCAD

In order to use the new material, you need to close and restart SpaceCAD.